

FILE NAME: BILINGUAL
G02447_17_BILInstructSheetUnicPogoJumper.ai
REVISION #: 1
DATE: 10/5/18

APPLICATION:
Adobe Illustrator CC
DESIGNER:
Jeff DeSantis


Black

NOTE: PROOF IS NOT COLOR ACCURATE

Kidoozie™ Unicorn Pogo Jumper

Assembly Instructions

G02447



Set Contains:

- A Foam head
- B 2 Handle pieces
- C Elastic cord attached to jumping base.

To Assemble:

- Step 1** Push looped end of elastic cord into bottom base of foam head.
- Step 2** Push handle piece with threading through hole.
- Step 3** Twist other handle piece through hole and screw securely together.

 EPOCH EVERLASTING PLAY
75D LACKAWANNA AVENUE
PARSIPPANY, NJ 07054 USA
1-800-631-1272
www.EpochEverlastingPlay.com


Made in China
Fabriqué en Chine
©2018 Epoch Everlasting Play LLC

FRONT (English)

Kidoozie™ Licorne pogo sauteur

Instructions d'assemblage

G02447



L'ensemble contient :

- A Tête en mousse
- B Poignée en 2 parties
- C Cordon élastique relié à la base sauteuse.

Pour assembler :

- Étape 1** Poussez l'extrémité en boucle du cordon élastique dans la base inférieure de la tête en mousse.
- Étape 2** Passez la partie de la poignée à filetage à travers le trou.
- Étape 3** Tournez l'autre partie de la poignée à travers le trou et vissez solidement ensemble.

 EPOCH EVERLASTING PLAY
75D LACKAWANNA AVENUE
PARSIPPANY, NJ 07054 USA
1-800-631-1272
www.EpochEverlastingPlay.com

Made in China
Fabriqué en Chine
©2018 Epoch Everlasting Play LLC

BACK (French)